

| <b>Menu Description</b>        | <b>Sport 36'</b> |
|--------------------------------|------------------|
| Clean (1) Oil (2) Both (3)     | <b>3</b>         |
| Simultaneous (1) Separate (2)  | <b>1</b>         |
| Start Clean Distance           | <b>0</b>         |
| Oil Only Dust Yes (1) No (0)   | <b>1</b>         |
| Oil Pattern Distance (feet)    | <b>36</b>        |
| Forward Shift to 2nd Speed     | <b>1</b>         |
| Forward Shift to 3rd Speed     | <b>12</b>        |
| Forward Shift to High Speed    | <b>36</b>        |
| <b>FWD Oil PAD #8R</b>         | <b>230</b>       |
| <b>FWD Oil PAD #7R</b>         | <b>240</b>       |
| <b>FWD Oil PAD #6R</b>         | <b>23</b>        |
| <b>FWD Oil PAD #5R</b>         | <b>24</b>        |
| <b>FWD Oil PAD #1L</b>         | <b>230</b>       |
| <b>FWD Oil PAD #2L</b>         | <b>240</b>       |
| <b>FWD Oil PAD #3L</b>         | <b>23</b>        |
| <b>FWD Oil PAD #4L</b>         | <b>24</b>        |
| Return Shift Down to 3rd Speed | <b>36</b>        |
| Return Shift Down to 2nd Speed | <b>12</b>        |
| Return Shift Down to Low Speed | <b>1</b>         |
| <b>REV Oil PAD #8R</b>         | <b>160</b>       |
| <b>REV Oil PAD #7R</b>         | <b>160</b>       |
| <b>REV Oil PAD #6R</b>         | <b>16</b>        |
| <b>REV Oil PAD #5R</b>         | <b>17</b>        |
| <b>REV Oil PAD #1L</b>         | <b>160</b>       |
| <b>REV Oil PAD #2L</b>         | <b>160</b>       |
| <b>REVOil PAD #3L</b>          | <b>16</b>        |
| <b>REV Oil PAD #4L</b>         | <b>17</b>        |